Fjords®
Relaxation Made Beautiful

Modern Living Collection
Battery Information

KS RC-Battery-Pack MC 463 (item no. 001 06 00008 04)






MC172 - 502349 US-Version item no.: 001 06 10010 04




Extension Cable 502268 item no.: 001 06 00019 04

FEATURES AND BENEFITS

- Battery will be supplied with approximately an 80% pre-charge.
- Battery can be stored for up to 18 months.
- Smart controller checks the status of each of 5 battery cells regularly.
- If power level falls below 30%, it will beep, reminding the user to recharge the battery.
- Control panel on the side of the chair will illuminate to RED when battery level falls below 30%.
- When battery is in regular use, it is recommended to recharge every 3 months.
- When battery is fully charged, the control panel on chair will illuminate GREEN when in use.



Green lights on the control panel indicate a battery that is fully charged.



Red lights on the contol panel indicate that battery level is below 30% and must be recharged before it enters SAFE MODE. An auditory BEEP will also sound.

SLEEP MODE FUNCTION


- Sleep Mode gets activated automatically when power level falls to below 20%.
- The Sleep Mode Safety Feature prevents the battery from completely draining which would destroy the battery cells and prevent it from charging.
- If chair falls into sleep mode, the chair will cease to operate until the battery is fully charged to 100% capacity (approximately 8 hours).

Fjords®
Relaxation Made Beautiful

Modern Living Collection
Battery Information

CHARGING THE BATTERY

- Modern Living Recliners come pre-wired to charge the battery. Simply plug the adaptor into the Battery Charging Portal.
- The battery comes pre-charged at 80% capacity.
- When battery life reaches 30% it will beep and operating controls will illuminate Red.



MOTORS AND WIRING FOR MODERN LIVING RECLINERS

1. Lithium Battery
2. Internal Transformer
3. Connect / Disconnect Battery and Operate with Direct Power. NOTE: When you disconnect the battery and go direct power, you will no longer be charging the battery, even when plugged into wall.
4. Battery Charging portal (outside of chair)
5. Motor for backseat
6. Motor for footrest

Direct Power

Batteries will eventually wear out. To order a new battery, simply contact the selling dealer. If that happens, Modern Living Recliners also come with a direct power option. Simply disconnect the battery and plug in the wall adapter as shown below. NOTE: This method by-passes the battery. As a result, the battery will not charge if you are operating direct power.



